

spill magnet



Multi-purpose, super-absorbent spill powder Spill Magnet quickly absorbs and retains unpleasant and hazardous liquid spills.

Ideal for use the quick cleaning up of unpleasant bodily fluid spills.

Overview

The answer for spill containment of unpleasant and hazardous bodily fluid spills!

Quick acting, non-leaching Spill Magnet is a fast absorbing powder granule that absorbs and retains up to 40 times its own weight!

A blend of acrylic polymer granules that swell and adsorb liquids on contact, Spill Magnet forms a gel which retains absorbed liquid and will not leach.

- Fast working
- Highly absorbent
- Non-leaching - retains liquids

How to use

- Using supplied scoop, apply around and over the spill.
- Allow 2-3 minutes for Spill Magnet to expand into a gel.
- Brush in gently to produce a dry, sweepable material.
- Once removed, clean and disinfect the affected area as appropriate.
- Dispose of waste according to risk of material spill.

Note:

- Spill Magnet has no antimicrobial properties.
- Also suitable for use on chemical and hydrocarbon liquid spills.

What can be absorbed

Bodily fluids:

- Blood
- Vomit
- Urine

Chemicals

- Acids –inorganic
- Aldehydes
- Aromatics
- Diesel
- Halides - alkyl
- Hydrazines
- Nitrososo compounds
- Paints
- Sulphites
- Acids –organic
- Aliphatics
- Caustics
- Epoxides
- Halides - inorganic
- Ketones
- Oils
- Peroxides
- Varnish
- Adhesives
- Amides
- Cresols
- Esters
- Halogenated aliphatics
- Lubricants
- Olefins
- Phenols
- Not suitable for use on Hydrofluoric acid or fluoride compounds
- Adhesives
- Amines –alkyl
- Cyanates
- Ethers
- Nitriles
- Organophosphates
- Sulphates
- Alcohols
- Amines –aryl
- Cyanides
- Glycols
- Heavy metals
- Nitro compounds
- Oxides - alkylene
- Sulphides

Pack sizes

Description	Case Size	Order Code	NHS SC Code
5kg bucket with scoop	Individual	DET-W-225	HFL8681

Endurocide® is the healthcare division of Bio Technics Ltd, based in the UK. Endurocide® is a Registered Trademark of Bio Technics Ltd.



Bio Technics Ltd.

Linton Business Park, Gourdon, Aberdeenshire, Scotland, UK DD10 0NH

Tel: +44 (0) 1561 361515 Email: info@biotechnics.co.uk Web: www.biotechnics.co.uk



FM 26816 EMS 575801